

# QUICK DROP Line Guide Installation Instructions

Remove existing halyard line from outrigger eyelets

Identify port (labeled P) and starboard (labeled S) QUICK DROP Line Guides. (Please note: there is no difference between port and starboard line guides; they are labeled P or S for your convenience while installing)

QUICK DROP Line Guides with black knobs

Locate black knob line guides

Install black knob line guides to the first eyelet at tip of outrigger

Turn thumb screw on line guide until secure

QUICK DROP Line Guides with white knobs

Locate white knob line guides

If you only have one white knob line guide, we recommend installing it to the last eyelet on outrigger although it will work on any eyelet

Turn thumb screw on line guide until secure

Strand halyard line through QUICK DROP Line Guides

Go fishing!

QUICK DROP Line Guide Removal Instructions

Simply loosen thumb screws on QUICK Drop Line Guides, remove and stow away



ANCO PRECISION INC.  
3191 SW 11<sup>TH</sup> STREET BLDG 200  
DEERFIELD BEACH FL. 33442  
954.429.3703